


Scooter Bag User Manual

ninebot

This product can be used to various Segway-Ninebot products, such as Mi Electric Scooter, Mi Electric Scooter Pro, Ninebot KickScooter.

Installation Diagram:

Tie the upper magic tapes to the horizontal handle, and tie the back-side magic tapes to the vertical stem. Fasten them before use.



Precautions:

1. The maximum load of this scooter bag is 1 kg. Don't overload it.
2. Do not block the front light when fitting the Ninebot KickScooter.

For aftersales and contact information, please visit www.segway.com for more details.